



Automatic Controller Quick Programming Guide

Press NEXT to advance from one programming step to the next step

Press \rightarrow to advance within a programming step

Set Time/Day: Press +/ON or -/OFF to set data. Press and hold to advance quickly. Press \rightarrow and follow \blacktriangleright to set year, month, day and time

Set Run Times: Press PROG to select program A, B or C (looping program) Press +/ON or -/OFF to set station run times Press \rightarrow to advance to next station Press and hold both +/ON and -/OFF to turn station to OFF

Set Water Days: Press → to choose CALendar, INTerval, Odd or Even Press +/ON or -/OFF to select

Set Start Times: Press +/ON to set start time Press \rightarrow to advance to start 2 and 3 Press and hold +/ON and -/OFF to turn start time OFF

Set % Scaling: Select program, entered run times are 100% Set from 0% (program off) to 200% to adjust all run times

Set Manual: Select station(s), set run time(s). Select AUTO to start sequence. Press -/OFF to turn OFF

Set Semi-Auto: Press +/ON to start sequence Press -/OFF to turn sequence OFF

System Off: Leave light on to turn controller OFF

AUTO Run position: Controller will return here after 3 minutes of inactivity