



# Quick Reference Guide

**Use this guide for quick reference when you want to:**

|   |                  |
|---|------------------|
| <b>Change Time and Day .....</b>                    | <b>page 2</b>    |
| <b>Review or Change Watering Day Schedule .....</b> | <b>pages 2-3</b> |
| <b>Review or Change Program Start Times .....</b>   | <b>page 4</b>    |
| <b>Review or Change Zone Run Times .....</b>        | <b>page 5</b>    |
| <b>Use Manual Operations.....</b>                   | <b>page 6</b>    |
| <b>Turn Off The Timer.....</b>                      | <b>page 7</b>    |
| <b>Use The Rain Delay Feature .....</b>             | <b>page 7</b>    |
| <b>Use The Season Adjust Feature.....</b>           | <b>page 8</b>    |

**Questions? Call The Toro Help Line 1-800-367-8676**

**Quick Reference Guide**

## To Change Time and Day

1. Turn the control dial to the SET TIME/DAY position.
2. To set the current hour press the +/ON or -/OFF button.
3. Press the NEXT button.
4. To set the current minute, press the +/ON or -/OFF button.
5. Press the NEXT button.
6. To set the current day, press the +/ON or -/OFF button until the current day is flashing.
7. If finished, return the control dial to the AUTO/ON position.

## To Review or Change Watering Day Schedule

### Calendar Schedule

---

1. Turn the control dial to the SET WATERING DAYS position.
2. Set PROGRAMS switch to select the desired program.
3. Press the +/ON or -/OFF button to select **CAL.**
4. Press the NEXT button.
5. To select the day (flashing), press the +/ON button. To remove the day, press the -/OFF button. Repeat this step until only the desired watering days are shown.
6. Return the control dial to the AUTO/ON position.

## Interval Schedule

---

1. Turn the control dial to the SET WATERING DAYS position.
2. Set PROGRAMS switch to select the desired program.
3. Press the +/ON or -/OFF button to select **Int.**
4. Press the NEXT button.
5. To select the Interval day (1–7), press the +/ON or -/OFF button.
6. Press the NEXT button.
7. To select the Interval start day, press the +/ON or -/OFF button.
8. If finished, return the control dial to the AUTO/ON position.

## Turning Off A Program

---

1. Turn the control dial to the SET WATERING DAYS position.
2. Set PROGRAMS switch to select the desired program.
3. Press the +/ON or -/OFF button to select **OFF.**
4. If finished, return the control dial to the AUTO/ON position.

## To Review or Change Program Start Times

1. Turn the control dial to the SET PROGRAM START TIMES position.
2. Set PROGRAMS switch to select the desired program.
3. Press the +/ON or -/OFF button to select the desired program start time number.
4. Press the NEXT button.  
**Note:** To remove a start time, select OFF by pressing the +/ON and -/OFF buttons at the same time, and continue at step 8.
5. To set the hour, press the +/ON or -/OFF button.
6. Press the NEXT button.
7. To set the minutes, press the +/ON or -/OFF button.
8. Press the NEXT button. The next program start time number will begin flashing.
9. To review or change another start time, return to step 3.
10. When finished, return the control dial to the AUTO/ON position.

## To Review or Change Zone Run Times

1. Turn the control dial to the SET ZONE RUN TIMES position.
2. Set PROGRAMS switch to select the desired program.
3. Zone number 1 will be flashing and its current run time or OFF will be shown. To select a different zone number, press the +/ON or -/OFF button.
4. Press the NEXT button.
5. To set the run time, press the +/ON or -/OFF button.
6. Press the NEXT button.
7. To review or change a run time for another zone, repeat steps 5 and 6.
8. If finished, return the control dial to the AUTO/ON position.

**Note:** To remove a zone run time, select OFF by pressing the +/ON **and** -/OFF buttons **at the same time**.

## Manual Operations

### Starting Programs Manually

---

**Note:** Watering programs can be started individually or set to start in order.

Additional programs set to start will operate one at a time in alphabetical order regardless of the order selected.

1. Ensure the control dial is in the **AUTO/ON** position.
2. Position the **PROGRAMS** switch to select a program you wish to start.
3. Press the **MANUAL START** button.
4. To select additional programs, repeat step 2 and 3.

### To Pause Watering

---

Press the **+ / ON** **and** **- / OFF** buttons **at the same time**.

### To Resume Watering (when paused)

---

Press the **NEXT** button.

### To Cancel Watering

---

Press the **+ / ON** **and** **- / OFF** buttons **at the same time - two times**.

### To Skip Zones

---

Press the **NEXT** button one time.

### To Adjust The Zone Run Time

---

Press the **+ / ON** button to increase run time or the **- / OFF** button to decrease run time.

## Turning Off The Timer

When the control dial is turned to the **OFF** position, the timer immediately shuts off any watering operation currently in progress. Leaving the control dial in the **OFF** position will prevent all automatic and manual watering operations.

For extended shutdown of the sprinkler system, leave the control dial in the **OFF** position.

Timer operation is resumed by turning the control dial to the **AUTO/ON** position.

## Rain Delay Feature

This feature enables all watering operations to be delayed from 1 to 7 days.

1. Turn the control dial to the **RAIN DELAY** position.
2. To set the number of Rain Delay days, press the **+ / ON** or **- / OFF** button.
3. Turn the control dial to the **RAIN DELAY** position.

**Note:** To cancel the Rain Delay, turn the control dial momentarily to the **OFF** position.

**Note:** The Rain Delay number will automatically decrease as each day passes. When the number reaches 0 (zero), automatic operation will resume.

## Season Adjust Feature

**Note:** Please refer to the User Guide for detailed information regarding the Season Adjust feature.

1. Turn the control dial to the SEASON ADJUST position.
2. Set PROGRAMS switch to select the desired program.
3. Press the +/ON or -/OFF until the desired adjustment value (10% to 200%) is flashing.
4. Return the control dial the AUTO/ON position.