

Ezy Automatic Tap Timer

User Guide


conveniently irrigated – even when you are not home. You win more free time and have a lush, green garden and beautiful, healthy plants. Used for garden watering applications With a POPE Ezy Automatic Tap Timer, your garden will be reliably and


Key Features :

- Easy to install and program
- Easy LCD programs for garden watering system
- 180 minutes
- Rain sensor compatible
- Low battery indicator
- Fits 3/4" and 1" taps




Ezy Automatic Tap Timer @ POPE





How to install .


- The timer must be vertically installed.
- 2. Place a new 9v. ALKALINE battery into the battery compartment as finally re-attach the timer face to the body. alkaline battery into the compartment (D) and re-screw the cover back, and (A), and unscrew the cover (B & C) of the battery compartment, insert the 9v time of the timer). See pic. below. Firstly, firmly pull the front face off timer shown below (using an old battery will decrease the overall operational



- Test to ensure the unit is operational. Simply press the Man. button to turn on water manually and you will hear the click sound when the solenoid valve operates.
- 4. Program your timer prior to connecting to the tap. Or, if the timer body is timer body to set up the program and then attach it back to the timer body already connected to the tap, take the front part of control unit off the

symbol " C " or " DAYS " for different

operations as follows:



E. Rain Sensor function :

Choosing the symbol "C" for weekly days program set up,

1. Depress OK button when C symbol is flashing, by pressing left and right

watering programs after pressing OK button, and then pressing up and down buttons to decide it's watering or not ($0n\ \text{\ensuremath{\mathfrak{S}}}$ Off) at the selected dates after buttons to select which dates (from Monday to Sunday) you want to set up

pressing OK button.

off in raining days, but the manual watering program is still valid for operation with default closing type and the auto watering program being set will be shut This timer is compatible with rain sensor (not included) which must be used

F Low Battery Feature :

2. After how many days as interval and which date to start by pressing OK

interval being selected for watering after pressing OK button. which date (Monday to Sunday) you want to start how many days as an buttons to select how many days from 1 to 15 days as an interval you want

to set up watering programs and then pressing left and right buttons to select

new 9V. battery has been installed displayed on the screen and the valve will be shut off automatically until a When battery power drops below 2.40V., icon of lower voltage will be



battery has been installed, the LCD panel will be back to main screen as pic. below. No programming over 1 minute after the 9V. G. Power Saving Feature:

A STAR P jon 0 P A NINS

C. Auto function switched to On or Off:

After dates selection by pressing OK button, you will be led into the mode

0

P

A

0

P

A

STAR P | ON

0

P

DAYS e(-

9

MO TU WE TH FR SA SU

direction and pressing the OK button.

start times and watering duration from 1 to 180 minutes following by the button, you will be led into the mode "START" to set up 8 different watering

180 minutes following by the direction and pressing the OK button. "START" to set up 8 different watering start times and duration from 1 to

watering programs being set or to turn them off temporarily. Depress the "Menu" button and you will see arrow symbol flash above the " A " by pressing the arrow button " > " and the "OK" button to turn on the



D. Manual Watering Program Setting :

Depress OK button when "DAYS" symbol is flashing, by pressing up and down

Choosing the symbol "DAYS" for interval days program set up.

STAR P jon

STAR P ION

SNIM |

0

P

A

0

P

A

the manual watering duration as buttons and then OK button to decide minutes by pressing the up and down Depress the "Man." button to select manual watering from 1 minute to 180

0

P

A

A

E



- 4. Water Source: Use cold mains water only, If it is a gravity fed
- if your water pressure exceeds 1000Kpa;
- --- if you use any kind of pump to draw water;
- --- if you use any liquid other than water that is flammable.
- --- if the water supplies pressure is unstable

Disassembling the timer improperly will void all warranties. 1. Make sure you use only new Alkaline battery. Keep clear of dirt and debris which may block the solenoid valve and cause the set program to stop.

Battery Care and Timer Maintenance :

- To prevent corrosion, always remove the battery when the timer is not in use for long periods of time or when the battery is low.
- It is recommended that a new 9V. battery is installed if you are going away for an extended period of time. This will ensure watering as programmed

Performance Specifications:

Recommended Water Pressure: 150 to 1000Kpa. Maximum operating pressure 1000kpa. In higher pressure areas, use a

pressure reducer on the tap.

Recommended operating temperature : 4° to 60°C The tap timer should not be subjected to freezing temperatures or frosts We recommend removing the tap timer from the tap during colder months winter time), particularly where temperatures drop below 4°C.

- Fit the tap timer to your garden tap:
- using the 1" tap connector by removing the 3/4" bush included directly to the tap. For 1" (25mm) taps - attach the tap timer to the tap For 3/4" (20mm) taps - attach the tap timer with the 3/4" bush included
- Hand tighten the 3/4" or the 1" tap nut until secure. Do not use tools to tighten. Do not over tighten.
- 7. The water can now be turned on

How To Program :

There are 3 major icons printed under the LCD screen as follows:

- : Current time adjustment
- P : Watering program set up
- A : Auto function switched to On or Off

A. Current time adjustment.

by pressing 4 arrow buttons and OK commence the current time adjustment will see arrow symbol flash above the Depress the "Menu" button and you button to set up the current time. "O" icon, press the "OK" button to





- 3. Battery: 1 x 9V. Alkaline Battery only
- watering system, ensure that you use a tap filter from tap.
- This product is not suitable for use :
- if you use bore or unfiltered water;
- explosive or corrosive; or

Troubleshooting :

- If battery is running low, the solenoid valve will close automatically.
- Make sure the tap is turned on.
- Make sure the auto watering function switch is not turned to Off position

- This Pope EZY Automatic Tap Timer has a 12 month guarantee against to the replacement of the product at our discretion for a period of 12 gardening application. Our obligation under this guarantee is limited efects in material and workmanship when used in normal home months from the date of purchase.
- 2. Use of this product outside of the performance specifications or improper disassembling of this product will void the warranty



Poye⁶⁶ is a Registered Trademark of **Tora Australia Pry Ltd**53 Howards Road Boverlay SA 5009 info au¢thoro com
1300 134 880

www.popeproducts.com.gu