



SIMPLE SET *AUTOMATIC TAP TIMER*




Your Pope® Simple Set Automatic Tap Timer gives you all the convenience of set and forget garden watering.

Just select how long and how often you want to water your garden and the Pope® Simple Set Automatic Tap Timer will do the rest.

Key features:

- Time delay feature
- Water resistant cover
- Low battery indicator
- Easy to use
- Simple to install
- Time saving
- Runs on 2 x AAA alkaline batteries (no wiring required)
- Includes tap adaptor, to fit 3/4" and 1" taps
- Guaranteed for 12 months
- Can be set to run up to 24 times per day
- Can be set to run up to 2 hours at a time
- Durable body

Your Pope® Simple Set Automatic Tap Timer



HOW TO OPERATE

1. Install and only use 2 new AAA ALKALINE Batteries in the battery compartment (Using old batteries will decrease the overall operational time of the timer).
2. Test to ensure the unit is operational. Simply turn the Run Time dial to the “On” position. Within a few seconds you should hear the timer mechanism operate.
3. Program your timer prior to connecting to the tap.
4. Use the FREQUENCY dial to determine how often you want to water
5. Use the RUN TIME dial to determine how long you want to water.
6. Ensure the cover is firmly screwed onto the timer.
7. Fit the 3/4” tap connector or the 1” adaptor to your garden tap. If using the 1” adaptor, attach it directly to the tap.

8. Loosen the collar until the fitted 3/4” tap connector is loose. Then holding the timer steady with one hand, fit to the tap.

9. Hand tighten the collar until secure.
DO NOT OVERTIGHTEN.

10. The water can now be turned on.

Please note: Watering will commence when the first “frequency cycle” you have set has passed. For example if your Frequency Dial is set to 1 hour, the first watering cycle will commence one hour after you have set the program....and continue hourly thereafter.

Using ON will allow the water to flow from the tap.

Using OFF will prevent water flowing from the tap, even if the tap is on.

Watering Frequency – Select every 1, 2, 3, 4, 6, 8,12, 24, 48,or 72 hours, or every week

Watering Run time – Select 1, 3, 5, 10, 15, 20, 30, 60, 90, or 120 minutes

To Program:

Once attached to tap simply select your watering frequency and your run time.

The dials can be turned both clockwise and anti-clockwise without damaging the mechanism.

To set watering twice daily – Select 12

To set watering daily – Select 24

To set watering every second day - Select 48

To set watering once a week – Select week

Time Delay Feature:

You can delay your watering start time using the Time Delay Feature. Use the point of a pen to depress the button for each hour you want to delay watering. You can delay watering in 1 hourly intervals only, up to a maximum of 12 hours. So to delay watering for 3 hours, depress the Time Delay button 3 times.

Low Battery Indicator:

The Low Battery Indicator light flashes continuously while the batteries still have sufficient power to operate the timer. When the battery power is low the Low Battery Indicator will remain on, and the valve will be shut off. The light will go out when the battery is completely flat.

Maintenance:

Make sure you only use new Alkaline batteries. Keep clear of dirt and debris. Ensure water is not accidentally sprayed into battery compartment.

Ensure cover remains screwed firmly onto timer.

Timer cannot be reassembled if taken apart. Disassembling will void all warranties.

Performance Specifications

Water pressure: Maximum up to 600 kPa.
If operating in a higher water pressure area, use a pressure reducer.

Batteries: 2 x AAA Alkaline

Use with cold water only

Trouble shooting

- If batteries are running low the valve will close automatically.
- Ensure that the Run Time dial is not set to Off.
- Check that the Frequency selected is longer than the Run Time. Eg. do not set a 120 minute run time and a 2 hour frequency.
- Make sure the tap is turned on.

Guarantee

This Pope® product has a 12 month warranty against defects in materials and workmanship when used with mains water supply in normal home garden watering applications.

This product is not suitable for use with water and bore pumps.

The Pope Simple Set – Dial Automatic Tap Timer will operate in pressures up to 600kPa.

Use a pressure reducing device in higher pressure areas. Use of this product under these conditions without a pressure reducer will void the warranty.

Disassembling of this product will also void the warranty



Toro Australia

Pope® is a Registered Trademark of
Toro Australia Pty Limited
53 Howards Road, Beverley SA 5009