


TWILIGHT GOLF CUP - CHARGER Li-lon Battery Charger User Guide



Specifications

For use with Li-Ion Battery Pack 18650 11.1V, 2600mAh. 5-6 hour charge time. Indoor use only.

Charger	
Input:	<u>Features</u>
120Vac, 60Hz, 0.3A	Over Voltage Protection:
	Auto restart
Output:	Over-Current Protection:
12.6Vdc, 1.8A Max, 78.0% efficiency	Auto-restart without damage
	Short-Circuit Protection:
Environmental:	Output can be shorted without damage
Operation: -10°C (14°F) to+40°C (104°F) / Humidity: <90%	

Charging the Twilight Golf Cup (TWGC)

Prior to initial use, the TWGC should be fully charged to ensure expected illumination time.

- 1. Turn the TWGC over and place the power button into the "Charge" (out) position.
- 2. Remove the protective cover from the TWGC charging port (Figure 1).
- 3. With AC adapter unplugged, plug the charger cable into the TWGC charging port (Figure 2).
- 4. Plug AC adapter into wall outlet. "Unit X" LED will indicate various charge operations as shown below.





5. Charge TWGC in a well-ventilated area. Do not place charger on or near heat-producing sources when charging TWGC.

LED Color	Meaning
Red	Charge-in-process
Green	Charge complete, maintenance mode
Off	Charge suspended, timer fault, overvoltage, sleep mode, or battery absent

- **Charge suspended:** Possible battery overheating or damage reset by disconnecting unit and allow cooling. If continued, replace battery pack.
- Overvoltage: Battery voltage high, or damaged battery reset by disconnecting unit. If continued, replace battery pack.
- Sleep mode: Reset by disconnecting and connecting unit. LED will indicate Red or Green.
- Battery absent: Connect unit. LED will indicate Red or Green.