



Ezy Run Timer 1010376


The Ezy Run is a two zone garden watering timer which has 12 pre-determined watering cycles for each zone (A and B). Additionally, you can set the frequency of watering to every day, every 2nd day, every 3rd day, every 4th day, every 5th day, every 6th day or every 7th day.

Battery Installation

Pull out the battery holder from the back of the timer and insert two (2) AA Alkaline batteries, making sure that the orientation is as shown on the diagram in the holder. Re-insert the battery holder.

Setting the Clock

Use the \oplus and \ominus buttons to increase or decrease the time displayed. Holding the button down allows you to scroll through the time faster.



The clock displays 12 hour time, so make sure that the correct AM or PM is selected.

Selecting a Watering Cycle using the Dial

Turn the dial to select one of the 12 available settings:

- water at 6AM for 15, 30 or 60 minutes
- water at 6AM and 6PM for 15, 30 or 60 minutes
- water at 7AM for 15, 30 or 60 minutes
- water at 7AM and 7PM for 15, 30 or 60 minutes.

If your water pressure is too low to effectively water with two hoses at the same time, set Zone A to water at 6AM and Zone B to water at 7AM.

Selecting a Watering Cycle using the Dial

Use the \odot button to set up the watering frequency. The options are:

- 1st - every day
- 2nd - every second day
- 3rd - every third day
- 4th - every fourth day
- 5th - every fifth day
- 6th - every sixth day
- 7th - every seventh day

The selected watering frequency is applied to both zones.

Installing the Timer

Attach the timer to a tap and connect a hose to each of the outlets.

Turn the tap on and leave it turned on. The Ezy Run will control the flow of water to the two hoses.

Manual Operation

To turn the water on manually at any time (other than the programmed times) turn the zone dial (A or B) to ON.

To stop watering, turn the dial to OFF.